

Thermometer Calibration

Fill a small container with packed crushed ice and water.

Insert the thermometer into the water and ice. Be careful that the stem of the thermometer does not touch the sides or bottom of the container.

After a few minutes, adjust the calibration nut (located under the dial) so that the indicating needle reads 32° F.

Note: a suitable small-diameter probe with a dial range of 0° to 220°F should be used to measure meat patties and other thin foods.

Refer to manufacturer's instructions when calibrating a digital thermometer.



contact us at
(330)723-9688 option 3
for more information about food safety